

Oasys



Oasys GSA

Export Reference

Oasys

YOUR IDEAS BROUGHT TO LIFE

8 Fitzroy Street
London
W1T 4BJ
Telephone: +44 (0) 20 7755 4515

Central Square
Forth Street
Newcastle Upon Tyne
NE1 3PL
Telephone: +44 (0) 191 238 7559

e-mail: oasys@arup.com
Website: oasys-software.com

Oasys GSA

© Oasys 1985 – 2021

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Contents

GSA export	5
COM	6
Data	6
Model (model)	6
Location (location)	6
History (history)	6
Axis (axis)	6
Grid plane (grid_plane)	7
Lists (list)	7
Nodes (node)	7
Eléments (element)	7
Members (member)	9
Assemblies (assembly)	9
1D properties (section)	10
2D properties (prop_2d)	10
3D properties (prop_3d)	10
Results	11
Cases (case)	11
Permutations (permutation)	11
Global (result_global)	11
Nodes (result_node)	12
1D elements (result_elem_1d)	12
2D elements (result_elem_2d)	12
3D elements (result_elem_3d)	13
Springs (result_spring)	13
Assembly (result_assembly)	13
Element positions & interpolation functions	14
1D elements	14
2D elements	14
3D elements	15

GSA export

It is possible to export GSA data and results for creation of a database. Certain model data is exported followed by results for nodes, elements and assemblies. Results for analysis cases are exported. Results for combination cases are exported for cases which have a single set of results, e.g. simple combinations. Envelope combinations are output as a max and a min value.

The extraction creates a folder with the same name as the GSA model and information if written to a single file for each data or results type.

The extraction uses GsaShell with the command line:

```
gsashell --action export-database --gsafile <gsa_file> --filetype <type> --input <in_file>
```

or

```
gsashell --action export-database --gsafile <gsa_file> --filetype <type> --points <num> --include-interesting <option>
```

where

- `gsa_file` is the file to be exported,
- `type` is csv or sql and
- `in_file` is an input file give details of what is to be exported
- `num` is the number of points along a beam element
- `option` is true or false for including interesting points in the export

The input file is a simple text file of key value pairs separated by a tab. The following options can be specified:

- `node` – node list (default all)
- `element` – element list (default all)
- `member` – member list (default all)
- `assembly` – assembly list (default all)
- `case` – case list (default all)
- `num_points` – number of points for output along beam elements (default 5)
- `interesting_points` – true/false to include/exclude results at interesting points on beam elements (default false)
- `delimiter` – the field delimiter for csv files (typically , | or tab)

The output of model data is unaffected by the entity lists.

COM

The export is available through COM using the command

```
ExportToCsv(BSTR pathname, LONG numPoint, VARIANT_BOOL interestingPoints,  
            VARIANT_BOOL combinations, BSTR delimiter, SHORT* retCode)
```

With arguments

`pathname` – folder for output

`numPoint` – number of points along beam elements

`interestingPoints` – flag to include interesting points

`combinations` – flag to include combinations (not used at present)

`delimiter` – field separator (usually a comma)

Data

Model and results data can be exported to csv or sql files. They create a series of tables as detailed below.

Model (model)

- `job_number`
- `initials`
- `title`
- `subtitle`
- `calculation_header`
- `steel_code`
- `concrete_code`
- `notes`
- `guid` – model guid

Location (location)

- `country` – ISO abbreviation
- `north` – angle to north
- `elevation`
- `latitude`
- `longitude`
- `currency`

History (history)

- `date`
- `time`
- `user`

- notes

Axis (axis)

- id – axis id
- name
- type
- origin_x, origin_y, origin_z – origin
- xaxis_x, xaxis_y, xaxis_z – x vector
- yaxis_x, yaxis_y, yaxis_z – y vector
- zaxis_x, zaxis_y, zaxis_z – z vector

Where type is one of CARTESIAN, CYLINDRICAL or SPHERICAL.

Grid plane (grid_plane)

- id – grid plane id
- name
- type
- axis
- elevation

Where type is STOREY or PLANE.

Lists (list)

- id – list id
- name
- type
- description
- expanded – expanded description

Where type is NODE, ELEMENT or MEMBER and expanded is an expanded list separated by commas.

Nodes (node)

- id – node id
- name
- colour
- position_x, position_y, position_z – position
- axis
- restraint
- spring – spring property id
- mass – mass property id
- damper – damper property id

Where restraint is a string containing x, y, z, xx, yy, zz for restrained degrees of freedom of pin (equivalent to xyz) or fix (equivalent to xyzxyzz)

Eléments (element)

- id – element id
- name
- colour
- type
- prop_1d_id – 1D property id
- prop_2d_id – 2D property id
- prop_3d_id – 3D property id
- group_id
- num_node – number of nodes
- node_1 ... node_8 – nodes
- orientation_angle
- dummy
- parent_member
- member_type – parent member type
- offset_x1
- offset_x2
- offset_y
- offset_z
- release_1 – (string, only for beam elements)
- release_2

Where nodes are 8 fields filled as appropriate to the element type. Element types are:

- BEAM
- BAR
- ROD
- TIE
- STRUT
- TRI3
- QUAD4
- TRI6
- QUAD8
- TETRA4
- PYRAMID5
- WEDGE6
- BRICK8
- CABLE
- SPRING
- DAMPER
- LINK

All with two nodes unless the number is specified in the type. If a beam type element has three nodes the third node is the orientation node.

And the parent member types are

- BEAM
- COLUMN
- 1D_GENERIC
- SLAB
- WALL
- 2D_GENERIC
- 3D_GENERIC

The property ID is null if not relevant for this element.

Members (member)

- id – member id
- name
- colour
- type
- prop_1d_id – 1D property id
- prop_2d_id – 2D property id
- prop_3d_id – 3D property id
- group_id
- topology – (string)
- type_1d
- type_2d
- mesh_size
- orientation_angle
- dummy
- offset_x1
- offset_x2
- offset_y
- offset_z
- release_1 – (string, only for 1D members)
- release_2
- BIM id

Where the member types are

- BEAM
- COLUMN
- 1D_GENERIC
- SLAB
- WALL
- 2D_GENERIC
- 3D_GENERIC

And the type 1D options are from the 1D element types above, and the type 2D options are

- LINEAR
- QUADRATIC

- RIGID

Assemblies (assembly)

- Id – assembly id
- name
- storey – (TRUE or FALSE)
- geometry
- node_1
- node_2
- node_3
- internal – (string)
- dim_y – dimension y
- dim_z – dimension z

Where the geometry options are LINEAR, CIRCULAR and LAGRANGE

1D properties (section)

- id – property id
- name
- colour
- material – material type
- gr
- grade_id – material grade id
- description
- perimeter – (string in form $(x_0, y_0) (x_1, y_1) \dots$)
- pool
- area
- $i_{yy} - I_{yy}$
- $i_{zz} - I_{zz}$
- $j - J$
- $k_y - k_{yy}$
- $k_z - k_{zz}$
- volume_per_length – volume per unit length

2D properties (prop_2d)

- id – property id
- name
- colour
- material – material type
- grade_id – material grade id
- description
- thickness

3D properties (prop_3d)

- id - property id
- name
- colour
- material – material type
- grade_id – material grade id

Results

Results should be available for analysis case and combination cases with syntax

- A_i for analysis case i
- C_i for combination case i where the combination case is simple
- C_{ipj} for combination case i , permutation j

Results denoted by a * mean the result is output as a value/permutation pair. The permutation field has the same title as the field to which it relates but has '_perm' appended. For analysis cases and simple combinations the permutation will be blank.

Cases (case)

- case_id
- case_type – (Analysis, Combination)
- case_number
- case_permutation
- description

Permutations (permutation)

- case_id
- case_number
- case_permutation
- description

Global (result_global)

- case_id
- case_type – (Analysis, Combination)
- case_number
- case_permutation
- load_x, load_y, load_z, load_xx, load_yy, load_zz – total load
- reaction_x, reaction_y, reaction_z, reaction_xx, reaction_yy, reaction_zz – total reaction
- mode
- frequency
- load_factor
- modal_stiff – modal stiffness

- modal_geo_stiff - modal geometric stiffness
- modal_mass
- effective_mass_x, effective_mass_y, effective_mass_z, effective_mass_xx, effective_mass_yy, effective_mass_zz

Where items from mode down only have values for dynamic and buckling analysis as appropriate

Nodes (result_node)

- id - node id
- case_id
- case_type - (Analysis, Combination)
- case_number
- disp_x, disp_y, disp_z, disp_xx, disp_yy, disp_zz*
- reaction_x, reaction_y, reaction_z, reaction_xx, reaction_yy, reaction_zz*
- constraint_x, constraint_y, constraint_z, constraint_xx, constraint_yy, constraint_zz*
- vel_x, vel_y, vel_z, vel_xx, vel_yy, vel_zz - velocity*
- acc_x, acc_y, acc_z, acc_xx, acc_yy, acc_zz - acceleration*

1D elements (result_elem_1d)

- id - element id
- case_id
- case_type - (Analysis, Combination)
- case_number
- position_r - relative position (r in range [0:1])
- disp_x, disp_y, disp_z - displacement*
- force_x, force_y, force_z*
- moment_x, moment_y, moment_z*

2D elements (result_elem_2d)

- id - element id
- case_id
- case_type - (Analysis, Combination)
- case_number
- position_r, position_s - relative position (r,s in range [0:1])
- disp_x, disp_y, disp_z - displacement*
- force_xx, force_yy, force_xy - in-plane force N*
- moment_xx, moment_yy, moment_xy - moment M*
- shear_x, shear_y - shear force*
- stress_top_xx, stress_top_yy, stress_top_zz, stress_top_xy, stress_top_yz, stress_top_zx*
- stress_middle_xx, stress_middle_yy, stress_middle_zz, stress_middle_xy, stress_middle_yz, stress_middle_zx*
- stress_bottom_xx, stress_bottom_yy, stress_bottom_zz, stress_bottom_xy, stress_bottom_yz, stress_bottom_zx*

- *strain_top_xx, strain_top_yy, strain_top_zz, strain_top_xy, strain_top_yz, strain_top_zx**
- *strain_middle_xx, strain_middle_yy, strain_middle_zz, strain_middle_xy, strain_middle_yz, strain_middle_zx**
- *strain_bottom_xx, strain_bottom_yy, strain_bottom_zz, strain_bottom_xy, strain_bottom_yz, strain_bottom_zx**
- *pore_pressure*

3D elements (result_elem_3d)

- id – element id
- case_id
- case_type (Analysis, Combination)
- case_number
- position_r, position_s, position_t – relative position (r,s,t in range [0:1])
- disp_x, disp_y, disp_z – displacement*
- stress_xx, stress_yy, stress_zz, stress_xy, stress_yz, stress_zx*
- *strain_xx, strain_yy, strain_zz, strain_xy, strain_yz, strain_zx**
- *pore_pressure*

Springs (result_spring)

- id – entity id
- type – (NODE or ELEMENT)
- case_id
- case_type – (Analysis, Combination)
- case_number
- position_r – relative position (r as 0 or 1)
- disp_x, disp_y, disp_z – displacement*
- force_x, force_y, force_z*
- moment_x, moment_y, moment_z*

Assembly (result_assembly)

- id – assembly id
- case_id
- case_type – (Analysis, Combination)
- case_number
- position_r – relative position (r in range [0:1])
- disp_x, disp_y, disp_z – displacement*
- rotn_x, rotn_y, rotn_z – rotation*
- drift_x, drift_y, drift_z*
- force_x, force_y, force_z*
- moment_x, moment_y, moment_z*

Element positions & interpolation functions

Results on elements need to be located at a given position. This can be done with respect to an embedded axis system

1D elements

The position is given by a coordinate r in the range $[0:1]$



The interpolation function is given by

$$x(r) = \sum_i h_i x_i$$



where

$$h_1 = (1 - r)$$

$$h_2 = r$$

2D elements

The position is given by a coordinates r and s in the range $[0:1]$



The interpolation function is given by

$$x(r, s) = \sum_i h_i x_i$$

Where the quad interpolation functions are

$$h_1 = (1-r)(1-s)$$

$$h_2 = r(1-s)$$

$$h_3 = r s$$

$$h_4 = (1-r)s$$

and the triangle interpolation functions are


$$h_1 = (1-r)(1-s)$$

$$h_2 = r(1-s)$$

$$h_3 = (1-r)s$$

3D elements

The position is given by a coordinate r, s and t in the range [0:1]



The interpolation function is given by

$$x(r, s, t) = \sum_i h_i x_i$$

Where the brick interpolation functions are

$$h_1 = (1-r)(1-s)(1-t)$$

$$h_2 = r(1-s)(1-t)$$

$$h_3 = r \cdot s(1-t)$$

$$h_4 = (1-r)s(1-t)$$

$$h_5 = (1-r)(1-s)t$$

$$h_6 = r(1-s)t$$

$$h_7 = r \cdot s \cdot t$$

$$h_8 = (1-r)st$$

the wedge interpolation functions are

$$h_1 = (1-r)(1-s)(1-t)$$

$$h_2 = r(1-s)(1-t)$$

$$h_3 = (1-r)s(1-t)$$

$$h_4 = (1-r)(1-s)t$$

$$h_5 = r(1-s)t$$

$$h_6 = (1-r)st$$

the pyramid interpolation functions are

$$h_1 = (1-r)(1-s)(1-t)$$

$$h_2 = r(1-s)(1-t)$$

$$h_3 = r \cdot s(1-t)$$

$$h_4 = (1-r)s(1-t)$$

$$h_5 = (1-r)(1-s)t$$

and the tetra interpolation functions are

$$h_1 = (1-r)(1-s)(1-t)$$

$$h_2 = r(1-s)(1-t)$$

$$h_3 = (1-r)s(1-t)$$

$$h_4 = (1-r)(1-s)t$$